

Agitator Whisker Kit Upgrade Instructions



Kit Part Number: 010876

Kit Contents:

The kit contains the following items:

- (2) Agitator Whisker
- (4) Shaft Collar
- (1) 9/64 Drill Bit
- (1) 1/16 Hex Key



Procedure:

• Remove the (2) existing whiskers from the agitator by pulling them out with a pair of pliers.



- Turn the hopper upside down.
- Use the 9/64 drill bit to clean out the hole. For the older black whiskers, the drill will enlarge the hole.





SIGGON Agitator Whisker Kit **Upgrade Instructions**



Insert the new whisker into the old hole from the bottom side until the collar is against the bottom of the agitator



- Install the second collar onto the whisker from the inside of the hopper.
- Slide the collar down against the agitator plate and secure in place using the hex key.

