



Technical Bulletin

Date: October 6th, 2016

Product Line: Bambi

Models: Bambi Mobility Sled

Subject: Introduction of the 4-Wheel Mobility Sled

Background

SEI has provided the Mobility Sled to help transport large Bambi Buckets since 2012. The original product had three wheels and featured a brake that applied automatically when the handle was lowered. The cart was designed to roll into a CH-47 helicopter. This system works well for operators using all three ramps, but is not effective if the customer is only using two ramps. Because many customers do not regularly use three ramps, SEI has introduced a four wheeled version of the mobility sled. The new mobility sled uses a different braking system from the previous version. There is a brake on each front wheel and they must be engaged and released manually. The new design is shown in the images below.

Recommendations

The new Mobility Sled can be ordered under part number 012770. The three wheeled Mobility Sled will still be available as part number 009383.

Customers with three wheeled Mobility sleds that would like to convert them to the four wheeled version can do so by purchasing 2x 012861 (wheel and brake assembly) and 1x 012779 (winch mount assembly) to replace the front wheel and brake assembly on the three wheeled cart.



Bambi
BUCKETS
Driven by Innovation



This Technical Bulletin is available on the SEI website. <http://www.sei-ind.com/resources/manuals>

For further details, please contact the following SEI representatives.

Contact

Shawn Bethel
Division Manager, Firefighting Division
604-946-3131 ext. 119
shawn@sei-ind.com

Robert Button
Product Engineer, Firefighting Division
604-946-3131 ext. 423
robert@sei-ind.com



SEI Industries Ltd. 7400 Wilson Avenue, Delta, B.C. Canada V4G 1H3
T: 604.946.3131 seisales@sei-ind.com www.sei-ind.com